

CLAIMS

WE CLAIM:

- 1 1. A liquid crystal (LC) optical performance monitor (OPM), comprising:
2 a C-polarizer having a birefringent crystal having a first face and a second
3 face for receiving a collimated beam and separating the collimated beam into a P-
4 polarization beam and a S-polarization beam;
5 a waveplate coupled to the second face of the crystal for rotating the S-
6 polarization beam by 90 degrees, thereby causing the rotated S-polarization beam to have
7 the same polarization as the P-polarization beam; and
8 a liquid crystal tunable filter for receiving and processing the P-
9 polarization beam and the rotated S-polarization beam from the C-polarizer.
- 1 2. The LC OPM of Claim 1, further comprising a small beam collimator
2 coupled to the first face of the C-polarizer, the small beam collimator receiving an input
3 beam and collimating the input beam to become the collimated beam.
- 1 3. The LC OPM of Claim 1, further comprising a beam collimator coupled to
2 the first face of the C-polarizer, the beam collimator providing a minimal space
3 separation between the P-polarization beam and the rotated S-polarization beam.
- 1 4. The LC OPM of Claim 2, wherein C-polarizer and the small beam
2 collimator are rotated to match a polarization orientation of the LC material inside a LC
3 cavity of the LC tunable filter.

1 5. The LC OPM of Claim 4, further comprising a photodiode for receiving
2 the P-polarization beam and rotated S-polarization beam.

1 6. The LC OPM of Claim 1, further comprising a bi-cell photodiode having a
2 first cell and a second cell, the first cell of the bi-cell photodiode receiving the P-
3 polarization beam, the second cell of the bi-cell photodiode receiving the rotated S-
4 polarization beam.

5

1 7. A method of a LC OPM, comprising:
2 separating a collimated beam into a P-polarization beam and a S-polarization
3 beam;
4 rotating the S-polarization beam by 90 degrees, thereby the S-polarization beam
5 having the same polarization as the P-polarization beam; and
6 scanning to filter the spectral information of the S-polarization beam and the P-
7 polarization beam by a liquid crystal tunable filter.

1 8. The method of Claim 8, further comprising collimating an input beam to
2 generate the collimated beam.

1 9. The method of Claim 10, further comprising matching the alignment of the
2 LC filter in the direction of the liquid crystal.

1 10. The method of Claim 10, further comprising applying a voltage to an LC
2 tunable filter to affect the rotated S-polarization beam and the P-polarization beam.

1 11. A method of a LC OPM, comprising:
2 separating a collimated beam into a first beam comprising a first linear
3 polarization and a second beam comprising a second linear polarization that is orthogonal
4 to the first linear polarization;
5 rotating the polarization of one of the first beam or the second beam by 90
6 degrees, thereby causing the first and second beams to have the same polarization; and
7 scanning to filter the spectral information of the first beam and the second beam
8 by a liquid crystal tunable filter.

1 12. The method of Claim 11, further comprising collimating an input beam to
2 generate the collimated beam.

1 13. The method of Claim 12, further comprising matching the alignment of the
2 LC filter in the direction of the liquid crystal.

1 14. The method of Claim 13, further comprising applying a voltage to an LC
2 tunable filter to affect the rotated first beam and the second beam.